

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
North Las Vegas, NV 89031
TEL: 702-399-1423
FAX: 702-399-1431
8am-5pm Pacific Time
Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.




4716.001

U.S Models Only

1985-2001 Yamaha V-Max

Stage 7 - Race Use Only

For mildly tuned machines using individual filters.
Must be used with a good aftermarket exhaust system with a high flow baffle
K&N filter #RU-2989



This graph shows a typical gain with a Dynojet jet kit.

WARNING

**NO SMOKING!
NO OPEN FLAME!
WHILE INSTALLING
YOUR DYNJET KIT**





Parts List

4	Main Jet	DJ165
4	Main Jet	DJ175
4	Main Jet	DJ190
4	Fuel Needle	DNT426
4	Main Air Jets	DCO402
4	E-Clips	DE0001
4	Adjusting Washers	DW0001
4	Slide Springs	DSP044
1	Plug Drill	DD #5/32
1	Screw	DS0001
1	Slide Drill	DD #19
1	Tool	DT0002
1	Glue	DA0001
2	Manifolds	DJ7010
1	Orifice	DJ7011
1	Breather Assembly	DJ7012

STAGE SEVEN INSTRUCTIONS

1. Remove the vacuum slides from the carbs. Remove the stock needles and spacers, noting the order of assembly (Fig. A). With the DD #19 drill bit provided, enlarge the slide lift hole (Fig. A). **Do not drill the needle hole.**
2. Install the Dynojet needles on groove #4 from the top. Use all stock spacers (Fig. A). Install the small Dynojet washers above the E-clip. Install the Dynojet slide springs (DSP044) in place of the stock slide springs. After installing the slides in the carbs be sure to check slide movement manually before air box installation.
3. Remove the stock main jets and replace with the Dynojet main jets provided. It is not necessary to break the carb rack apart to remove the main jets. Remove float bowl drain plugs, then slightly loosen the main jet. Use a needle to completely remove the main jet. If you are running a modified stock exhaust install the DJ165 main jets. If you are using an aftermarket exhaust or slip-on with a high flowing baffle use the DJ175 main jets. Be sure that the jet you are changing is the main jet.
4. Locate the fuel mixture plug (Fig. B). If you see a screw head proceed to adjusting procedure. With the DD #5/32 drill bit provided, carefully drill through the plugs. **Note:** The mixture screw is directly underneath this plug, be ready to pull back on the drill the instant you break through. Use screw provided to secure and remove the plug. Carefully turn mixture screws clockwise until lightly seated, then back out 2.5 turns.
5. If you are installing the complete stage 7 kit remove the stock V-boost assembly and unplug the wires to the servo motor. If you wish to retain the stock V-boost assembly go to step 7.
6. Install the Dynojet manifolds (DJ7010) in place of the stock V-boost assembly.
7. Insert the orifice supplied (DJP7011) into the stock crankcase vent tube as shown in (Fig. D).
8. Place the carbs on the bench with bell mouths facing up. Install the main air correctors (DCO402) with flat end facing the carbs, into the main air jet ports (Fig. C). Using the tool supplied (DT0002) lightly tap the corrector until it seats tightly. With a toothpick, lightly dab glue on the outer edge of the corrector. Make sure no glue blocks the corrector holes. Complete this step on all four carbs.
9. Remove the stock oil filler cap. Install the breather assembly so that the threaded end screws into the oil filler hole and the assembly routes up between the rear cylinders and up the center of the four carbs. The two K&N filters with holes in the top of them go on the front two cylinders. Attach the two eyelets from the breather assembly into the airfilter holes. Attach the bottom of the breather assembly onto the stock crankcase breather hose. Check for proper throttle linkage operation before starting the bike.

Note: A medium or competition baffle must be used with this kit, or drill out the stock exhaust. If you notice a stumble or hesitation in the midrange after holding steady throttle, drill the pilot air jet with a DD #49 drill bit or remove the jet and replace with DJ190.



DYNOJET

4716.001

